

model: LD66 | product code: 44281 | Complies to EN13210

Lindam toddler runner



IMPORTANT KEEP FOR FUTURE REFERENCE


This toddler runner is suitable for children aged between 6 months and 4 years

- WARNING - Be aware of danger when using the Toddler Runner near automatic doors, escalators etc.
- WARNING - Remove any detachable reins when the harness is fitted into a *Child Use and Care Article**
- WARNING - Keep out of reach of children when not in use
- WARNING - Do not use this harness in motorised and power driven vehicles
- WARNING - Do not use your Toddler Runner if it shows signs of wear or damage

* The Toddler Runner is not designed to be attached to any other item such as a highchair etc, and should be removed completely for the comfort of your child when not being worn for its intended use


FITTING & ADJUSTING THE TODDLER RUNNER

1. Release the 2 side buckles as shown
2. Place the Toddler Runner over your child's head with the back pack at the rear.
3. Fasten the 2 side buckles.
4. Adjust the yellow and orange straps until you achieve a tight but comfortable fit.



ATTACHING THE REIN

Clip the rein onto the black elastic loop as shown making sure it is securely connected (Remove the rein if there is any risk of it getting caught or if it is not being used).



USING THE SUPPORT HANDLE

If your child is learning to walk or ride a bike you may want to use the Toddler Runner to give support and increase their confidence. Simply detach the reins and hold onto the yellow support handle whilst accompanying your child.

CLEANING

Clean your Toddler Runner by wiping with a damp cloth only and allow to dry naturally.

SAFETY

- The Toddler Runner is not a toy and must be handled by an adult
- Never let your child or other children play with the rein
- The Toddler Runner should not be used for climbing activities
- The Toddler Runner is not designed to teach your child to walk. It should be used to aid them after making their first steps.
- Always check that the straps are a tight but comfortable fit.
- Never leave children unattended even when harnessed into a *Child Use and Care Article**
- Regularly check your Toddler Runner for any signs of wear or damage